

Solution 6+6

Quick Reference Guide

ISSUE 1.20



BOSCH

Solution 6+6

Quick Reference Guide

Copyright © 1997 by Bosch Security Systems Pty Limited,
SYDNEY, AUSTRALIA

Document Part Number MA600Q

Document Issue 1.20

Printed 23 May 2006

This documentation is provided to suit *Solution 6+6* (CC600/LP600)

Firmware Revision 1.20 - 1.27

Hardware Revision D

Alarm Link Form - Software Version 1.20 - 1.27 = S6_V12

Copyright Notice

All rights reserved. No part of this publication may be reproduced, transmitted or stored in a retrieval system in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Bosch Security Systems Pty Limited.

Trademarks

Throughout this document trademark names may have been used. Rather than put a trademark symbol in every occurrence of a trademark name, we state that we are using the names only in an editorial fashion and to the benefit of the trademark owner with no intention of infringement of the trademark.

Notice of Liability

While every precaution has been taken in the preparation of this document, neither Bosch Security Systems Pty Limited nor any of its official representatives shall have any liability to any person or entity with respect to any liability, loss or damage caused or alleged to be caused directly or indirectly by the information contained in this book.

Bosch Security Systems Pty Limited reserves the right to make changes to features and specifications at any time without prior notification in the interest of ongoing product development and improvement.

Introduction

Thank you for choosing the **Solution 6+6** control panel for your installation. We are sure that you will find this system extremely flexible, reliable and easy to use.

Before using the system for the first time, we suggest that you read the section in this Quick Reference Guide called "Programming Using The Remote Codepad" to familiarise yourself with the basic programming methodology.

The Quick Reference Guide is supplied with the **Solution 6+6** to provide users with enough basic information to wire, configure and operate the system. Due to the systems many programmable features and options we suggest that you obtain the complete Installation Manual which provides detailed information on all system options and functions as well as detailed information on the numerous programming methods.

Programming

The programming options of this system are stored in a non-volatile EPROM. This memory will hold all the relevant configuration and user specific data even during a total power loss.

The data retention time is as long as ten years without power, therefore no reprogramming will be required after powering the system down.

The data can be altered as many times as required without the need for any additional specialised equipment. This memory is laid out in numerous locations, each of which holds the data for a specific function. In general, the entire programming sequence will consist of nominating the location then entering or altering the required data. You will repeat this procedure until all the data has been altered to suit your requirements. The factory default settings have been selected for Contact ID format.

Note: '15' is the maximum value that can be programmed into any location.

There are two programming modes. The Installer's Programming Mode and the Operators Programming Mode. Both modes have individual access codes and these two codes must always be programmed differently. The Master Code, as well as being able to arm and disarm the system gives access to the Operators Programming Mode. The Installer's Code only gives access to the Installer's Programming Mode and does NOT arm and disarm the system.

Programming of the **Solution 6+6** control panel can be carried out via any of the following four methods.

- ☐ System Codepad
- ☐ Hand Held Programmer (CC814)
- ☐ Programming Key (CC810)
- ☐ Alarm Link (Upload/Download) Software (CC816)

Note: For further information on the different programming options available for the **Solution 6+6, refer to the Installation Manual (MA600I).**

Programming Using The Remote Codepad

The system must be in the disarmed state with no flashing zone alarm memories, this can be achieved by entering the **MASTER CODE** followed by the **AWAY** button. The factory default Master Code is **2580**.

To access the Installer's Programming Mode, enter the four digit **INSTALLER CODE** followed by the **AWAY** button. The factory default Installer Code is **1234**. Three beeps will be heard and both the AWAY and the STAY indicators will flash simultaneously. If a long beep is heard, check the system for alarm memory. The codepad indicators will display the current data stored in the first location (LOCATION 000).

Data Value	Zone 1 Indicator	Zone 2 Indicator	Zone 3 Indicator	Zone 4 Indicator	Zone 5 Indicator	Zone 6 Indicator	Zone 7 Indicator	Zone 8 Indicator	MAINS Indicator
0									
1	✓								
2		✓							
3			✓						
4				✓					
5					✓				
6						✓			
7							✓		
8								✓	
9	✓							✓	
10									✓
11	✓								✓
12		✓							✓
13			✓						✓
14				✓					✓
15					✓				✓

Table 1: Zone Indicators When Programming

Example

To enter Installer's Programming Mode, enter the **INSTALLER CODE** followed by the **AWAY** button. Three beeps will be heard and the codepad will display the current data stored in "LOCATION 000".

To move to a particular programming location, enter the **LOCATION NUMBER** required followed by the **AWAY** button. The data of the new location will now be displayed.

To move to the next location, press the **AWAY** button. This will step you to the next location and the data in that location will be displayed via the ZONE indicators.

If you press the **STAY** button without previously entering a location number, the system will step back one location. To change data in the current location, enter the new value (0 – 15) followed by the **STAY** button. This will store the new data into the location and still leave you positioned at the same location.

To proceed to the next location, press the **AWAY** button. The next locations data will now be displayed.

To exit the Installer's Programming Mode, enter command **960** followed by the **AWAY** button. Two beeps will be heard and the system will return to the disarmed state.

For a more detailed explanation, refer to the *Solution 6+6* Installation Manual (MA600I).

Quick Start

The following steps will enable you to use the **Solution 6+6** panel with the default values as set in the factory. The default settings allow the panel to communicate in Contact ID format.

1. Connect AC plug pack to the control panel.
2. Check the operation of the red overload LED (LD1) on the PCB. In normal operation the LED will not illuminate. The MAINS indicator will remain on, as will the AWAY indicator. The unit is now in the armed state.
3. Enter the default Master Code **2580** followed by the **AWAY** button. The AWAY indicator will extinguish. The panel is now in the disarmed state. Installer's Programming Mode can now be accessed.
4. The back-up battery should now be connected.
5. Enter the factory default Installer Code **1234** followed by the **AWAY** button. The STAY and AWAY indicators will now flash simultaneously.
6. Enter the Primary Telephone Number followed by the Secondary Telephone Numbers and the Subscriber ID Number.
7. Set the time for the test reports if this option is required. Any other programming changes required can also be made, otherwise the factory programming default settings will be used.
8. Enter command **960** followed by the **AWAY** button to exit Installer's Programming Mode. The control panel will return to the disarmed state and is now ready for use.
9. Use the Master Code to set the date and time.

How To Set The New Date and Time

1. Enter your **MASTER CODE** followed by **6** and the **AWAY** button.
Three beeps will be heard and the STAY and AWAY indicators will begin to flash.
2. Enter the day, month, year, hour and minute using the (DD, MM, YY, HH, MM) format.
3. Press the **AWAY** button when finished.
Two beeps will be heard and the STAY and AWAY indicators will extinguish.

Zone Default Settings

The zone default settings are as listed in the table below.

Zone No	Zone Type
1	Delay-1
2, 3, 4 & 5	Handover
6	24 Hour

Table 2: Zone Default Settings

Note: The example given in this quick reference guide is a simplified description of how to configure the panel. This system offers many other programmable features, which are described in detail in the **Solution 6+6 Installation Manual (MA600I)**.

Installer's Programming Commands

There are several commands that can be invoked to perform the functions as listed below. These commands only operate while you are in the Installer's Programming Mode. To invoke the command, enter in the corresponding numerical code then press the **AWAY** button.

Command	Description
958	Enable and Disable Zone Status Mode When Using The Hand Held Programmer
959	Test Programming Key
960	Exit Installer's Programming Mode
961	Reset To Factory Default Settings (Contact ID Format)
962	Copy The Panel Memory To The Programming Key
963	Copy The Programming Key Data To The Panel Memory
964	Wipe Programming Key
965	Set Defaults For Domestic Dialling Reporting Format
966	Enable and Disable Automatic Stepping Of Locations During Programming
999	This Command Displays The Control Panel's "Software Version" Number When Using The Hand Held Programmer

Table 3: Installers Programming Commands

Installer Code Functions

Installer Code functions are designed to allow the installer to perform various system tests without the need to know a Master Code.

The **INSTALLER CODE** is entered followed by a **FUNCTION** digit then the **AWAY** button to activate the particular function.

INSTALLER CODE + **FUNCTION** + **AWAY**

These functions can only be carried out while the system is in the disarmed state.

Function	Description
0	Fault Analysis Mode
1	Reserved
2	Set Number Of Days Until The First Test Report
3	Event Memory Recall
4	Walk Test Mode
5	BOSCHSAT - Satellite Siren Service Mode
6	Initiate Modem Call
7	Turning Telephone Monitor Mode On and Off
8	Reserved
9	Send A Test Report

Table 4: Installer Code Functions

How To Enter Fault Analysis Mode

1. Enter your **INSTALLER CODE** followed by **0** and the **AWAY** button.
One or more zone indicators will illuminate to indicate the type of fault that has occurred.
2. Press the **AWAY** button to exit this function.

How To Set the Number Of Days Until The First Test Report

1. Enter your **INSTALLER CODE** followed by **2** and the **AWAY** button.
2. Enter the **No. OF DAYS** (01 – 99) until the first test report followed by the **AWAY** button.

How To Enter Event Memory Recall Mode

1. Enter your **INSTALLER CODE** followed by **3** and the **AWAY** button.
The event memory will be played back in reverse chronological order.
2. Press the **AWAY** button to exit this function, or wait until the function automatically terminates after the last event has been replayed.

How To Enter Walk Test Mode

1. Enter your **INSTALLER CODE** followed by **4** and the **AWAY** button.
The codepad will beep once every second while the system is in the walk test mode.
2. Unseal and seal the zones to be tested.
The codepad will sound one long beep while the horn speaker will sound one short beep every time a zone is sealed or unsealed.
3. Press the **AWAY** button to exit this function once all zones have been tested.

How To Activate Satellite Service Mode

1. Enter your **INSTALLER CODE** followed by **5** and the **AWAY** button.
The satellite siren will return to the normal operating state when the system has been armed.

How To Initiate A Modem Call

1. Enter your **INSTALLER CODE** followed by **6** and the **AWAY** button.

How To Turn Telephone Monitor Mode ON

1. Enter your **INSTALLER CODE** followed by **7** and the **AWAY** button.
Three beeps will be heard and the codepad will beep once every two seconds whilst this mode is active.

Telephone monitor mode allows the codepad to be used for a visual representation of data transmissions between the control panel and the base station receiver. The dialling sequence is also shown in this mode.

The codepad will beep once every two seconds while telephone monitor mode is turned on regardless of whether the system is in Installer's Programming Mode or normal operating mode. The first five zone indicators are used to display the progressive steps for a transmission to the base station receiver.

Zone LED	Event
1	Telephone Line Seized
2	Dialling Phone Number
3	Handshake Received
4	Data Is Being Transmitted
5	Kiss Off Received
None	Telephone Line Released

Table 5: Telephone Monitor Mode Indications

How To Turn Telephone Monitor Mode Off

1. Enter your **INSTALLER CODE** followed by **7** and the **AWAY** button.
Two beeps will be heard and the codepad will cease beeping once every two seconds.

How To Send A Test Report

1. Enter your **INSTALLER CODE** followed by **9** and the **AWAY** button.

Master Code Functions

Master Code functions are designed to allow those users that have the appropriate access level to perform certain functions of a supervisory level. These functions can only be carried out while the system is in the disarmed state.

The **MASTER CODE** is entered followed by a **FUNCTION** digit then the **AWAY** button to activate the particular function.

MASTER CODE + **FUNCTION** + **AWAY**

Function	Description
0	Arming or Disarming Both Areas At The Same Time (Partitioning Only)
1	Changing and Deleting User Codes
2	Changing Domestic Phone Numbers
3	Event Memory Recall
4	Walk Test Mode
5	Fault Analysis Mode
6	Setting The Date and Time
7	Turning Day Alarm On/Off
8	Reset Latched Outputs
9	Initiate Modem Call

Table 6: Master Code Functions

How To Arm Or Disarm Both Areas At The Same Time

1. Enter your **MASTER CODE** followed by **0** and the **AWAY** button.
Both areas will arm or disarm to follow the state of the area that the code was entered from.

How To Add Or Change A User Code

1. Enter your **MASTER CODE** followed by **1** and the **AWAY** button.
2. Enter the **USER NUMBER** that you wish to add or change followed by the **AWAY** button.
3. Enter all the digits for the **NEW CODE** followed by the **AWAY** button.

How To Delete A User Code

1. Enter your **MASTER CODE** followed by **1** and the **AWAY** button.
2. Enter the **USER NUMBER** that you wish to delete followed by the **AWAY** button.
3. Press the **STAY** button to delete the user code.

How To Change Domestic Phone Numbers

1. Enter your **MASTER CODE** followed by **2** and the **AWAY** button.
2. Enter all the digits for **PHONE No 1**, one digit at a time. You will notice as each digit is entered, the corresponding number on the keypad will illuminate.
3. After all the digits for the first telephone number have been entered, press the **STAY** button to separate the first telephone number and the second telephone number. If there is only one phone number, press the **AWAY** button to exit this function.
4. Enter all the digits for **PHONE No 2**, one digit at a time. You will notice as each digit is entered, the corresponding number on the keypad will illuminate.
5. After the last digit of the second telephone number has been entered, press the **STAY** button to separate the second telephone number and the third telephone number, otherwise, press the **AWAY** button to exit this function.

How To Enter Event Memory Recall Mode

1. Enter your **MASTER CODE** followed by **3** and the **AWAY** button.
The event memory will be played back in reverse chronological order.
2. Press the **AWAY** button to exit this function, or wait until the function automatically terminates after the last event has been replayed.

How To Enter Walk Test Mode

1. Enter your **MASTER CODE** followed by **4** and the **AWAY** button.
The codepad will beep once every second while the system is in the walk test mode.
2. Unseal and seal the zones to be tested.
The codepad will sound one long beep while the horn speaker will sound one short beep every time a zone is sealed or unsealed.
3. Press the **AWAY** button to exit this function once all zones have been tested.

How To Enter Fault Analysis Mode

1. Enter your **MASTER CODE** followed by **5** and the **AWAY** button.
One or more zone indicators will illuminate to indicate the type of fault that has occurred.
2. Press the **AWAY** button to exit this function.

How To Set The Date and Time

1. Enter your **MASTER CODE** followed by **6** and the **AWAY** button.
2. Enter the day, month, year, hour and minute using the format (DDMMYYHHMM) followed by the **AWAY** button.

How To Turn Day Alarm On and Off

1. Enter your **MASTER CODE** followed by **7** and the **AWAY** button.
Three beeps indicate that day alarm is turned on, two beeps indicate that day alarm is turned off.

How To Reset Latching Outputs

1. Enter your **MASTER CODE** followed by **8** and the **AWAY** button.

How To Initiate A Modem Call

1. Enter your **MASTER CODE** followed by **9** and the **AWAY** button.

User Code Functions

Function	Description
0	Arming or Disarming Both Areas At The Same Time (Partitioning Only)

Table 7: User Code Functions

Fault Analysis Mode

There are various system faults that can be detected by the control panel. When any of these are present the FAULT indicator will begin to flash and the codepad will beep once every minute. Hold the **5** button down for two seconds until two beeps are heard. The STAY and AWAY indicators will begin to flash in unison with the FAULT indicator. One or more zone indicators (1-8) will illuminate to indicate the current fault(s). Refer to the following table below.

Zone Indicator	Description
1	Low Battery
2	Date and Time
3	Sensor Watch
4	Horn Speaker Disconnected
5	Reserved
6	E ² Fault
7	Reserved
8	Communications Failure

Table 8: Fault Types

Hold Down Functions

Hold down functions have been incorporated to allow easy activation of specific operations. When a button is held down for two seconds, two beeps will be heard and a particular function will operate. The hold down functions are listed below.

Function	Description
AWAY	Arm The System In AWAY Mode
STAY	Arm The System In STAY Mode
0	Reserved
1	Horn Speaker Test
2	Bell Test
3	Strobe Test
4	Turning Day Alarm On and Off
5	Fault Analysis Mode
6	Initiate Modem Call
7	Reset Latching Outputs
8	Codepad ID Beeper Tone Change
9	Initiate Test Report

Table 9: Hold Down Functions

Location 000 - 015

Primary Telephone Number

0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

Location 016 - 031

Secondary Telephone Number

0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

Location 032 - 047

Callback Telephone Number

0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

Location 048

Dialling Format

1 = Australian DTMF

2 = Australian Decadic

3 = Alternate DTMF & Decadic (AUST)

4 = International DTMF

5 = Reversed Decadic

6 = Alternate DTMF & Reversed Decadic

1

Location 049

Handshake Tone

1 = HI-LO Handshake (Contact ID)

2 = 1400 Hz (Ademco TX @ 1900 Hz)

3 = 2300 Hz (Sescoa TX @ 1800 Hz)

4 = No Handshake Required

5 = Pager

1

Location 050

Transmission Format

1 = Contact ID

2 = 4 + 2 Expressed

3 = 4 + 2 Pulsed

4 = 4 + 2 Pulsed + Checksum

5 = 4 + 1 Pulsed + Universal

6 = 4 + 1 Pulsed Expanded

7 = 3 + 1 Pulsed Universal

8 = 3 + 1 Pulsed Expanded

9 = Reserved

10 = Reserved

11 = Domestic

12 = Basic Pager

13 = Reserved

14 = Reserved

15 = Reserved

1

Location 051

Transmission Speed

1 = 1 Pulse / Second

2 = 10 Pulses / Second

3 = 15 Pulses / Second

4 = 20 Pulses / Second

5 = 20 Pulses / Second FDL

6 = 40 Pulses / Second

2

Location 052 - 055

Subscriber ID Number

0 0 0 0

Location 056 - 059

Installer Code

1 2 3 4

Location 060

Ring Count

15 = Answering Machine Bypass 1

14 = Answering Machine Bypass 2 (New - Software Version 1.27 Onwards)

8

Location 061 - 100

User Codes

		Location 61 - 65		Location 66 - 70	
User Code 1		2 5 8 0 8		15 15 15 15 0	
		Location 71 - 75		Location 76 - 80	
User Code 3		15 15 15 15 0		15 15 15 15 0	
		Location 81 - 85		Location 86 - 90	
User Code 4		15 15 15 15 0		15 15 15 15 0	
		Location 91 - 95		Location 96 - 100	
User Code 6		15 15 15 15 0		0 15 15 15 1	
		Location 96 - 100			
User Code 7		15 15 15 15 0			
User Code 8					

Location 101

Day Alarm Mask

1 = Zone 1

2 = Zone 2

4 = Zone 3

8 = Zone 4

1

Location 102

Code Retries

6

Location 103

EOL Resistor Value

1 = 1K

2 = 1K5

3 = 2K2

4 = 3K3

5 = 3K9

6 = 4K7

7 = 5K6

8 = 6K8

9 = 10K

10 = 12K

11 = 22K

12 = Reserved

13 = Reserved









14 = Reserved

15 = Split EOL (3K3/6K8) For
6 Zones + 6 Tamper Zones

4

Location 104 - 151

Zones

Zone 1 Location 104 - 111	Zone 2 Location 112 - 119	Zone 3 Location 120 - 127
2 0 0 0 1 3 0 1	1 0 0 0 1 3 0 1	1 0 0 0 1 3 0 1
Zone 4 Location 128 - 135	Zone 5 Location 136 - 143	Zone 6 Location 144 - 151
1 0 0 0 1 3 0 1	1 0 0 0 1 3 0 1	12 0 0 0 1 3 3 1
		
Zone Type	Zone Option	Zone Pulse Count
		
Zone Pulse Count Time	Event Code Hundreds Digit	Event Code Tens Digit
		
Event Code Units Digit	Dialler Channel	

Each zone contains eight locations that are divided into two groups of four. The first four locations determine how the zone operates, while the second four locations contain the dialler reporting information.

Zone Types

There are thirteen different zone types to choose from. Each zone can be programmed as any of the zone types listed in the table below.

Zone Type	Description	Zone Type	Description
0	Instant	8	Delay-1 + Isolated In STAY Mode 1
1	Handover	9	Delay-2 + Isolated In STAY Mode 1
2	Delay-1	10	Reserved
3	Delay-2	11	Keyswitch
4	Reserved	12	24 Hour Burglary
5	Reserved	13	24 Hour Fire
6	Instant + Isolated In STAY Mode 1	14	Chime Only
7	Handover + Isolated In STAY Mode 1	15	Zone Not Used

Zone Options

Zone Option	Description
1	Lockout Siren
2	Lockout Dialler
4	Silent Alarm
8	Sensor Watch

Zone Pulse Count Settings

The pulse count settings for each zone can be programmed between 0 - 15.

Zone Pulse Count Time

Zone pulse count time is the time frame or period over which the number of pulses must register.

20 ms Loop Response Time Zone Pulse Count Time		150 ms Loop Response Time Zone Pulse Count Time	
0	0.5 Second	8	20 Seconds
1	1 Second	9	30 Seconds
2	2 Seconds	10	40 Seconds
3	3 Seconds	11	50 Seconds
4	4 Seconds	12	60 Seconds
5	5 Seconds	13	90 Seconds
6	10 Seconds	14	120 Seconds
7	15 Seconds	15	200 Seconds

Zone Descriptions

Use this table as a reference to indicate what each zone is connected to.

Zone	Description	Tamper Zone	Description
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	

Location 152 - 153

Bypass Codes (Zones 1 To 6)

9 9

Location 154 - 155

Trouble Codes (Zones 1 To 6)

9 9

Location 156 - 159

Codepad Duress

1 2 1 1

Location 160 - 163

Codepad Panic

1 2 0 1

Location 164 - 167

Access Denied (Code Retries)

4 2 1 1

Location 168 - 171

AC Fail

3 0 1 1

Location 172 - 175

Low Battery

3 0 9 1

Location 176 - 179

Sensor Watch

3 0 7 1

Location 180 - 181

Open/Close

8 9

Location 182 - 185

Test Reporting Time

Location 182

Location 183

Location 184

Location 185

Actual Hour Of The Day (Tens Digit)

Actual Hour Of The Day (Units Digit)

Repeat Interval In Days

Expansion Code For 4+2 Format

0 0 0 9

Location 186 - 209

Location 186 - 191 Location 192 - 197 Location 198 - 203

Output 1 1 14 0 0 0 0 Strobe 2 0 1 0 0 0 Relay 1 15 1 0 0 0

Location 204 - 209

Codepad 0 12 2 1 0 1

Output
Configurations

Event Type Polarity Time Base Time Multiplier

Location 210 - 211

Entry Timer 1

Location 210

Location 211

Increments Of 1 Second (0 - 15 Sec's)

Increments Of 16 Seconds (0 - 240 Sec's)

10 0

Location 212 - 213

Entry Timer 2

Location 212

Location 213

Increments Of 1 Second (0 - 15 Sec's)

Increments Of 16 Seconds (0 - 240 Sec's)

4 1

Location 214 - 215

Exit Time

Location 214

Location 215

Increments Of 1 Second (0 - 15 Sec's)

Increments Of 16 Seconds (0 - 240 Sec's)

12 3

Location 216 - 217

Entry Guard Time For STAY Mode

Location 216

Location 217

Increments Of 1 Second (0 - 15 Sec's)

Increments Of 16 Seconds (0 - 240 Sec's)

12 3

Location 218 - 219

Sensor Watch Time

Location 218

Location 219

Increments Of Days (Tens Digit)

Increments Of Days (Units Digit)

0 0

Location 220			
Codepad Lockout Time	Location 220	Increments Of 10 Seconds	<input type="text" value="0"/>
Location 221			
Siren Run Time	Location 221	Increments Of Minutes (0-15)	<input type="text" value="10"/>
Location 222			
Siren Sound Rate (Slow <-Sound-> Fast)			<input type="text" value="7"/>
Location 223			
Swinger Shutdown Count			<input type="text" value="0"/>
Location 224			
Dialler Options 1	1 = Enable Dialler Reporting Functions 2 = Enable Remote Arming Via The Telephone 4 = Enable Upload/Download Via Alarm Link 8 = Terminate "Alarm Link" Session On Alarm		<input type="text" value="5"/>
Location 225			
Dialler Options 2	1 = Send Open/Close Reports Only If A Previous Alarm Has Occurred 2 = Enable First To Open, Last To Close Reporting (Partitioning Only) 4 = Send Open/Close Reports When In STAY Mode 8 = Delay Siren Until Transmission Complete		<input type="text" value="0"/>
Location 226			
System Options 1	1 = Enable Forced Arming 2 = Enable BOSCH Smart Lockout 4 = Enable Monitoring Of Horn Speaker 8 = Enable Horn Speaker Beeps For Remote Control Operation		<input type="text" value="1"/>
Location 227			
System Options 2	1 = Enable Radio Key/Keyswitch Interface or Night Arm Station 2 = Enable Handover Delay To Be Sequential 4 = Enable Codepad Panic To Be Silent 8 = Enable Codepad Tamper To Be Silent		<input type="text" value="2"/>
Location 228			
System Options 3	1 = Enable Main Codepad To Display Data For Area 1 (Partitioning Only) 2 = Enable Resetting Of Sirens From All Areas (Partitioning Only) 4 = Ignore AC Fail 8 = Enable Pulse Count Handover		<input type="text" value="0"/>
Location 229			
Consumer Options 1	1 = Send Test Reports Only If The System Is Armed 2 = Enable Operation Of Siren & Strobe In STAY Mode 4 = Enable Answering Machine Bypass Only When Armed 8 = Enable Codepad Extinguish Mode		<input type="text" value="2"/>
Location 230			
Consumer Options 2	1 = Enable "User Code + 0 + AWAY" Function To Arm/Disarm Both Areas 2 = Enable Single Button Arming In AWAY Mode and STAY Mode 4 = Enable Single Button Disarming From STAY Mode 8 = Enable Alarm Memory Reset On Disarm		<input type="text" value="0"/>
Location 231 – 236			
Area 1 Zone Allocations			<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>
Location 237 – 242			
Area 2 Zone Allocations			<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>
Location 243 – 250			
Area/User Allocations			
Location 243	Location 244	Location 245	Location 246
Areas For User # 1 <input type="text" value="0"/>	Areas For User # 2 <input type="text" value="0"/>	Areas For User # 3 <input type="text" value="0"/>	Areas For User # 4 <input type="text" value="0"/>
Location 247	Location 248	Location 249	Location 250
Areas For User # 5 <input type="text" value="0"/>	Areas For User # 6 <input type="text" value="0"/>	Areas For User # 7 <input type="text" value="0"/>	Areas For User # 8 <input type="text" value="0"/>

Location 900

Disable Factory Default

0 = Defaulting Enabled
15 = Defaulting Disabled

0

Location 901 - 904

System Time

Location 901

Location 902

Location 903

Location 904

Hour Of The Day (Tens Digit)

Hour Of The Day (Units Digit)


Minute Of The Day (Tens Digit)

Minute Of The Day (Units Digit)

0 0 0 0

Connections For Split EOL Resistors For 6 Burglary Zones and 6 Tamper Zones

Enable 6 Burglary and 6 x 24 Hour Tamper Zone Operation Using (3K3/6K8) Configuration and N/C Switches.



If N/O Switches Are Used Both Zones Will Trip If Either Of The N/O Switches Are Closed

Figure 1: Connections For Split EOL Resistors For 6 Burglary Zones and 6 Tamper Zones

Wiring Diagram For Keyswitch Zone




Figure 2: Wiring Diagram For Keyswitch Zone

Wiring Diagram For Keyswitch Zone When System Has Been Partitioned




Figure 3: Wiring Diagram For Keyswitch Zone When Partitioned

Wiring Diagram




Figure 4: Wiring Diagram

Component Overlay




Figure 5: Component Overlay

Codepad Connections For Partitioned Systems




Figure 6: Wiring Diagram For Master Partitioned Codepad and Area Addressable Codepad

If the “Area Addressable” codepad is assigned to **Area 1**, DIP Switch 1 on the back of the remote codepad will need to be in the “ON” position. The following locations for Output 1 will need to be programmed.

[LOCATION 186 = 6, 187 = 0]

If the “Area Addressable” codepad is assigned to **Area 2** DIP Switch 2 on the back of the remote codepad will need to be in the “ON” position. The following locations for Output 1 will need to be programmed.

[LOCATION 186 = 6, 187 = 1]




Figure 7: Wiring Diagram For Two Area Addressable Codepads

The following DIP switch settings and locations must be programmed for the two “Area Addressable” codepads to operate correctly.

Area 1 Codepad

DIP Switch 1 on the back of the remote codepad will need to be in the “ON” position. The following location will also need to be programmed.

[LOCATION 228, Option Bit 1 must be enabled]

Area 2 Codepad - (Output 1)

DIP Switch 2 on the back of the remote codepad will need to be in the “ON” position. The following locations for Output 1 will also need to be programmed.

[LOCATION 186 = 6, LOCATION 187 = 1]