

Technical Information	Date: 16.12.2020 Official: Heckl Department: BT-FIR/MKP3
------------------------------	--

Tech. Information No.	2343 / 2020
Subject:	FSM 5.6 (FSM-2500/5000/10k): Known bug and Workaround

Short Description:	A high number of active alarms generated at the same time might lead to an unexpected error at the Client. Workaround to prevent this issue is available.
---------------------------	---

Hardware <input type="checkbox"/>	<input type="checkbox"/> Device	<input type="checkbox"/> Module	<input type="checkbox"/> PCBA
Software <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> Application	<input type="checkbox"/> Driver / Extension	<input type="checkbox"/> Firmware

Affected Products (details)	CTN	SAP no.	Aff. version	New version
Fire Monitoring System	FSM-2500/5000/10k	YBFR: F.01U.314.990 F.01U.314.991 YESB: F.01U.374.278 F.01U.374.695 F.01U.374.694	Client 5.6. 0.2131	--

Number of delivered devices		
Period of delivery	from:	to:
Affected serial numbers	from:	to:

Priority Level	Criterion
I <input type="checkbox"/>	The change has to be made immediately (see dates below)
II <input type="checkbox"/>	The change has to be made during the next inspection.
III <input checked="" type="checkbox"/>	Change has to be made, if the error pattern recurs and with new installations.
None <input type="checkbox"/>	General Information (like new tool, new feature, new SW release)

Action Plan	
<input checked="" type="checkbox"/>	Inform customers
<input type="checkbox"/>	Arrange re-work of stock (CSO)
<input type="checkbox"/>	Arrange re-work of stock (customer)
<input type="checkbox"/>	Arrange re-work of installed products
<input checked="" type="checkbox"/>	See detailed actions on following pages

Start Date		Completion Date	
-------------------	--	------------------------	--



Known bug:

A high number of active alarms generated at the same time might lead to an unexpected error at the Client.


Workaround:

To prevent this issue, after installation, the alert notification module shall be deactivated:

1. Go to File/Global settings/Local settings



2. Untick the checkbox “Alert notification module active”

**BU Manager**

Knauel

Clerk in Charge:

Heckl

Distribution

Distribution BU FIR Fire Systems	<input checked="" type="checkbox"/> Julian Tersteegen (BT-FIR/QMM), Claudia Majer (BT-FIR/QMM), Knauer Thomas (BT-FIR/MKP BT-FIR/MKT), Heckl Michael (BT-FIR/MKP3) <input checked="" type="checkbox"/> Angstenberger Josef (BT-FIR/MKR-EU) <input checked="" type="checkbox"/> Ong Kah Seong (BT-FIR/MKR-AP), Leonard Hew (BT-FIR/MKR-AP) <input checked="" type="checkbox"/> Paredes Ivan (BT/MKR-LA), Miers Christopher (BT/FIR-MKT) <input checked="" type="checkbox"/> Haug Stefan (BT-FIR/MKR-EU BT-FIR/MKA-EU) <input type="checkbox"/>
Distribution BU SC Intrusion Systems	<input type="checkbox"/> Petricoin Dennis (BT-SC/PAS2 BT-SC/PAS2-MKP), Dobson Roxanne (BT-SC/QMM2), Hupka Peter (BT-SC/PAS2-MKP5), Weissert Thorsten (BT-SC/PAS2-MKP5) <input type="checkbox"/> Kugler Gerhard (BT-SC/MKR6-EU), Berberian Alexandra (BT-SC/MKR-SEF), Shah Dhaval (BT-FIR/MKR-SEM), Gomez Arevalo Olga (BT/SEI-SCM), Malek Michal (BT-SC/MKR-SEP), van den Berg Quintin (BT-SC/MKR-SEZ), Kiselev Grigory (BT-FIR/MKR-SEO), Sonmez Onur (BT-FIR/MKR-SET), Cojocaru Laurentiu (BT-SC/MKR-SEA BT/SEA-SBD2), Riboli Stefano (BT-SC/MKR-SES), El Makhfi Otmane (BT-SC/MKR-SAN), Reuvers Willfried (BT-SC/MKR-SEB), Kuehlewind Uwe (BT-SC/MKR-SEC), Pillai Kiran (BT-SC/MKR-SEU), Karlsson Anders (BT-SC/MKR-SEN) <input type="checkbox"/> Cabral Paula (BT-SC/MKR-LA), Garms Paul (BT-SC/MKR2-NA) <input type="checkbox"/> Premo Mike (BT-SC/PAS2-ENG1), Meichelbeck Markus (BT-SC/PAS2-ENG5) <input type="checkbox"/> Schmidt Michaela (BT/MKW1) <input type="checkbox"/> Klein Alexander (BT/SC-MKI) <input type="checkbox"/>
Other parties affected	<input checked="" type="checkbox"/> Schrimpf Felix (BT-ASA/MKP BT-ASA/MKC) <input checked="" type="checkbox"/> Proyer Konrad (BT-ASA/SRA-EU BT-ASA/SRA2-EU), Dias Andre (BT-ASA/SRA-LA), Wilson Jim (BT-ASA/SRA-NA), Tan Woo Khiang (BT-ASA/SRA-AP) <input checked="" type="checkbox"/> Gill Manjit (BT-ASA/STS-UK) <input checked="" type="checkbox"/> Teleservice Support (SO/OMM1.3-MB) <input checked="" type="checkbox"/> Becker Oliver (BT-IE/PRM1), Goos Irina (BT-IE/PRM1) <input checked="" type="checkbox"/> Adelman Petra (BT-IE/EAP3) <input type="checkbox"/>