

<b>Technical Information</b>	Date: 13.04.2017 Official: Erhard Department: ST-IN/MKA-EU
------------------------------	--

<b>Tech. Information No.</b>	2096 / 2017
<b>Subject:</b>	IPP-MAP0005-2 MAP Power Supply, 150W

<b>Short Description:</b>	[EN] MAP Power Supply – Restriction for Firmware Update [DE] MAP Netzteil – Einschränkung für Firmware Aktualisierung
---------------------------	--

<b>Hardware</b> <input type="checkbox"/>	<input type="checkbox"/> Device	<input type="checkbox"/> Module	<input type="checkbox"/> PCBA
<b>Software</b> <input checked="" type="checkbox"/>	<input type="checkbox"/> Application	<input type="checkbox"/> Driver / Extension	<input checked="" type="checkbox"/> Firmware

Affected Products (details)	CTN	SAP no.	Aff. version	New version
Power Supply, 150W	IPP-MAP0005-2	F.01U.245.558		

<b>Number of delivered devices</b>		
<b>Period of delivery</b>	from: December 2011	to:
<b>Affected serial numbers</b>	from:	to:

Priority Level	Criterion
I <input type="checkbox"/>	The change has to be made <b>immediately</b> (see dates below)
II <input type="checkbox"/>	The change has to be made during the next inspection.
III <input type="checkbox"/>	Change has to be made, if the error pattern recurs and with new installations.
None <input checked="" type="checkbox"/>	General Information (like new tool, new feature, new SW release)

Action Plan	
<input checked="" type="checkbox"/>	Inform customers
<input type="checkbox"/>	Arrange re-work of stock (CSO)
<input type="checkbox"/>	Arrange re-work of stock (customer)
<input type="checkbox"/>	Arrange re-work of installed products
<input type="checkbox"/>	See detailed actions on following pages

<b>Start Date</b>		<b>Completion Date</b>	
-------------------	--	------------------------	--

Print out of this template is not subject of the updating service. Only the version in the Intranet is always up to date.

**Error(s) and Effect(s)**

[EN] Firmware update of the MAP power supply has been provided since system bundle 1.43.2. Before you start a firmware update, please check whether the device is suitable for a firmware update according to the table below.

	FW update not possible
CTN at device label	IPP-MAP0005
CPU Color marking	white
Current FW version	v1.01 or lower

The power supply is NOT suitable for a firmware update if at least one characteristic is true.


Attention: The attempt of a firmware update on an unsuitable device will result in permanent damage of the power supply.

[DE] Firmware-Aktualisierung des MAP Netzteils wird seit System-Bundle 1.43.2 bereitgestellt. Bevor Sie ein Firmware-Update beginnen, überprüfen Sie bitte gemäß der folgenden Tabelle, ob das Gerät für eine Firmware-Aktualisierung geeignet ist.

	FW-Update nicht möglich
CTN am Typenschild	IPP-MAP0005
CPU Farbmarkierung	weiss
Aktuelle FW-Version	V1.01 oder niedriger

Das Netzteil ist für eine Firmware-Aktualisierung NICHT geeignet, wenn mindestens ein Merkmal zutrifft.

Achtung: Der Versuch eines Firmware-Updates an einem nicht geeigneten Gerät führt zu einer dauerhaften Beschädigung des Netzteils.



**Attachment(s)**

<b>BU Manager</b>	Denzler ST-IN/RBU-EU	<b>Clerk in Charge:</b>	Erhard ST-IN/MKA-EU
-------------------	----------------------	-------------------------	---------------------

**Distribution**

Distribution BU FIR	<input type="checkbox"/> Celebi Guenay (ST-FIR/QMM), Knauel Thomas (ST-FIR/MKP ST-FIR/MKT), Heckl Michael (ST-FIR/MKP3) <input type="checkbox"/> Angstenberger Josef (ST-FIR/MKR-EU) <input type="checkbox"/> Lim Yong Gang (ST/SRM-AP), Leonard Hew (ST-FIR/MKR-AP), Quek Daniel (ST-CO/MKR2-AP) <input type="checkbox"/> Squarize Alex (ST/SRM-LA), Pinto Erik (ST/STS-LA ST-ASA/SRA-LA), Render Chelsea (ST/SRM-NA) <input type="checkbox"/>
Distribution BU IN	<input checked="" type="checkbox"/> Denzler Daniel (ST-IN/RBU-EU MKP-EU MKA-EU), Martin Diane (ST-IN/QMM), Kachel Roxanne (ST-IN/QMM), Klein Alexander (ST-IN/MKP-EU), Hupka Peter (ST-IN/MKP-EU), Weissert Thorsten (ST-IN/MKP-EU), Clemens Jasper (ST-IN/CLP-EU MKP-EU), Poessnecker Peter (ST-IN/CLP-EU) <input checked="" type="checkbox"/> Stauber Johannes (ST-IN/MKR-EU MKC-EU), Kugler Gerhard (ST-IN/MKR2-EU), Berberian Alexandra (ST-IN/MKR-SEF), Shah Dhaval (ST-FIR/MKR-SEM), Gomez Arevalo Olga (ST-IN/MKR-SEI), Malek Michal (ST-IN/MKR-SEP), Oppab Maria (ST-IN/MKR-SAN) <input type="checkbox"/> Cabral Paula (ST-IN/MKR-LA), Garms Paul (ST-IN/MKR-NA) <input checked="" type="checkbox"/> Borden Scott (ST-IN/ENG-EU), Meichelbeck Markus (ST-IN/ENG-EU) <input type="checkbox"/> Schmidt Michaela (ST-IN/MKW) <input type="checkbox"/>
Distribution BU ESS	<input type="checkbox"/> Tan Boon Chuan (ST-ESS/MKP1.4), Maier Holger (ST-ESS/MKP1.2), Wings Maarten (ST-ESS/MKP1.3), Redeker Bernd (ST-ESS/QMM), Jan von Rosenstiel (ST-ESS/MKP1.1), Jekelius Friederike (ST-ESS/MKP1) <input type="checkbox"/> Funke Thomas (ST-ESS/ENG) <input type="checkbox"/> Nikolas Mangold-Takao (ST-ESS/MKP1), Jaco Liebetrau (ST-ESS/MKT) <input type="checkbox"/> Markus Brack (ST-ESS/MKP2.3), Huse Istvan (ST/PRM2-EU) <input type="checkbox"/> Gary Deng (ST-PRM-CN), Roth Christy (ST-IN/MKR-NA), Claude Hochreutiner (ST-ESS/MKR-AP), Mauricio Santos (ST/SPS-LA), Mikhail Zyrianov (ST-ESS/MKR-EU ST-ESS/MKR-SEP) <input type="checkbox"/>
Other parties affected	<input type="checkbox"/> Schrimpf Felix (ST-ASA/PRM) <input type="checkbox"/> Proyer Konrad (ST-ASA/SRA-EU), Pinto Erik (ST-ASA/SRA-LA), Wilson Jim (ST-ASA/SRA-NA), Tan Woo Khiang (ST-ASA/SRA-AP) <input checked="" type="checkbox"/> Hemke Tobias (ST-ASA/STS3-EU); Gill Manjit (ST-ASA/STS-UK) <input checked="" type="checkbox"/> Teleservice Support (SO/OMM7.3-Mb) <input checked="" type="checkbox"/> Pedolzky Georg (ST-IE/PRM1) <input type="checkbox"/> Adelman Petra (ST-IE/EAP3) <input type="checkbox"/>

Print out of this template is not subject of the updating service. Only the version in the Intranet is always up to date.